```
1
2
  /** Descriptive File Name
3
4
  @Company
5
   ETML-ES
6
7
  @File Name
8
   mc32 serComm.c
9
10
  11
12
  13
  14
  /* Section: Included Files
15
  16
17
  #include "Mc32 serComm.h"
18
19
  #include <stdio.h>
20
  /* This section lists the other files that are included in this file.
21
23
24
  /* TODO: Include other files here if needed. */
25
26
  27
  28
29
  /* Section: File Scope or Global Data
  30
  31
32
  /* A brief description of a section can be given directly below the section
33
34
   banner.
35
36
  37
  /** Descriptive Data Item Name
38
39
40
  @Summarv
   Brief one-line summary of the data item.
41
42
43
  @Description
44
   Full description, explaining the purpose and usage of data item.
45
46
   Additional description in consecutive paragraphs separated by HTML
47
   paragraph breaks, as necessary.
48
   Type "JavaDoc" in the "How Do I?" IDE toolbar for more information on tags.
49
50
51
  @Remarks
52
   Any additional remarks
53
54
55
  56
  57
58
  // Section: Local Functions
  59
  60
61
62
63
  64
  65
66
  // Section: Interface Functions
  67
  68
69
70
   A brief description of a section can be given directly below the section
71
   banner.
73
```

```
// ****************************
 74
 75
 76
 77
      void serDisplayValues ( s bno055 data *bno055 data )
 78
 79
          char sendBuffer[66] = \{0\};
 80
          uint8 t i = 0;
 81
          static uint32 t ctnTimeout = 0;
 82
 83
          /* Preapare Gravity string */
          sprintf(sendBuffer, "DT: %d0 ms\tGravity : X = %04.031f\tY = %04.031f\tZ =
 84
          04.031f \n\r", (bno055 data->d time), bno055 data->gravity.x, bno055 data->
          gravity.y, bno055 data->gravity.z);
 85
          /* Transmit Gravity string */
 86
          do{
 87
              if(!PLIB USART TransmitterBufferIsFull(USART ID 1))
 88
 89
                  PLIB USART TransmitterByteSend(USART ID 1, sendBuffer[i]);
 90
                  i++;
 91
              }
 92
              ctnTimeout++;
 93
          }while((sendBuffer[i-1] != '\r')&&(ctnTimeout<TIME OUT));</pre>
 94
          i = 0:
 95
 96
          /* Preapare gyroscope string */
 97
          sprintf(sendBuffer, "Gyro
                                      : X = %04.031f\tY = %04.031f\tZ = %04.031f \n\r",
          bno055 data->gyro.x, bno055 data->gyro.y, bno055_data->gyro.z);
 98
          /* Transmit Gravity string */
 99
          do{
100
              if(!PLIB USART TransmitterBufferIsFull(USART ID 1))
101
102
                  PLIB USART TransmitterByteSend(USART ID 1, sendBuffer[i]);
104
              }
105
              ctnTimeout++;
106
          }while((sendBuffer[i-1] != '\r')&&(ctnTimeout<TIME OUT));</pre>
107
          i = 0;
108
109
          /* Preapare magnitude string */
110
          sprintf(sendBuffer, "Mag
                                      : X = %04.031f\tY = %04.031f\tZ = %04.031f\n\r",
          bno055 data->mag.x, bno055 data->mag.y, bno055 data->mag.z);
111
          /* Transmit Gravity string */
112
          do{
113
              if(!PLIB USART TransmitterBufferIsFull(USART ID 1))
114
115
                  PLIB USART TransmitterByteSend(USART ID 1, sendBuffer[i]);
116
                  i++;
117
              }
118
              ctnTimeout++;
119
          }while((sendBuffer[i-1] != '\r')&&(ctnTimeout<TIME OUT));</pre>
120
121
122
          /* Preapare linear acceleration string */
123
          sprintf(sendBuffer, "Accel : X = %04.03lf\tY = %04.03lf\tZ = %04.03lf \n\r",
          bno055_data->linear_accel.x, bno055_data->linear_accel.y, bno055_data->
          linear accel.z);
124
          /* Transmit Gravity string */
125
          do{
126
              if(!PLIB USART TransmitterBufferIsFull(USART ID 1))
127
128
                  PLIB USART TransmitterByteSend(USART ID 1, sendBuffer[i]);
129
                  i++;
130
              }
131
              ctnTimeout++;
132
          }while((sendBuffer[i-1] != '\r')&&(ctnTimeout<TIME OUT));</pre>
133
          i = 0;
134
135
          /* Preapare euler string */
136
          sprintf(sendBuffer, "Euler
                                       : H = %04.031f\tP = %04.031f\tR = %04.031f\n\r",
          bno055 data->euler.h, bno055 data->euler.p, bno055 data->euler.r);
137
          /* Transmit Gravity string */
138
          do{
139
              if(!PLIB_USART_TransmitterBufferIsFull(USART_ID_1))
```

```
140
               {
141
                   PLIB USART TransmitterByteSend(USART ID 1, sendBuffer[i]);
142
143
              }
144
              ctnTimeout++;
145
          }while((sendBuffer[i-1] != '\r')&&(ctnTimeout<TIME OUT));</pre>
146
147
148
          /* Preapare quaternion string */
          sprintf(sendBuffer, "Quater. : W = %05d\tX = %05d\tY = %05d\tZ = %05d\n\n\r",
149
          bno055_data->quaternion.w, bno055_data->quaternion.x, bno055_data->quaternion.y,
          bno055 data->quaternion.z);
150
          /* Transmit Gravity string */
151
          do{
              if(!PLIB USART TransmitterBufferIsFull(USART ID 1))
153
154
                   PLIB USART TransmitterByteSend(USART ID 1, sendBuffer[i]);
155
                   i++;
156
157
              ctnTimeout++;
158
          }while((sendBuffer[i-1] != '\r')&&(ctnTimeout<TIME OUT));</pre>
159
          i = 0:
160
161
      }
162
163
      void serTransmitString ( USART MODULE ID usartId, const char * msg )
164
165
          char bufferMsq[60] = \{0\};
166
          static uint32 t i = 0;
167
          static uint32 t ctnTimeout = 0;
168
169
          strncpy(bufferMsg, msg, strlen(msg));
170
          /* Transmit string */
171
172
          do{
173
              if(!PLIB USART TransmitterBufferIsFull(usartId))
174
175
                   PLIB USART TransmitterByteSend(usartId, bufferMsg[i]);
176
                   i++;
177
              }
178
              ctnTimeout++;
179
          }while((bufferMsg[i-1] != '\0')&&(ctnTimeout<TIME OUT));</pre>
180
181
      }
182
183
      void serTransmitbuffer ( USART MODULE ID usartId, char msg[], uint32 t lenght )
184
185
          uint32 t i = 0;
          uint32 t ctnTimeout = 0;
186
187
          /* Transmit string */
188
189
          do{
190
              if(!PLIB USART TransmitterBufferIsFull(usartId))
191
                   PLIB USART_TransmitterByteSend(usartId, msg[i]);
192
193
                   i++;
194
              1
195
              ctnTimeout++;
196
          }while((i < lenght)&&(ctnTimeout<TIME OUT));</pre>
197
          i = 0;
198
      }
199
200
      bool pollSerialSingleCmd(USART MODULE ID usartID, const char * command1)
201
      {
202
          static char charRead[30] = {0};
203
          static uint32 t readCnt = 0;
204
205
          // Get command's characters
206
          while((PLIB USART ReceiverDataIsAvailable(usartID))&&(readCnt < 30)){</pre>
207
              charRead[readCnt] = PLIB USART ReceiverByteReceive(usartID);
208
              readCnt++;
209
          // Command
210
```

```
211
          if(readCnt >= 30)
212
213
              /* Reset read counter */
214
              readCnt = 0;
              /* Clear read buffer */
215
216
              memset(charRead, 0, strlen(charRead));
217
218
          // Check occurence with commands
          if(strstr(charRead, command1) != NULL) {
219
220
             /* Reset read counter */
              readCnt = 0;
221
222
              /* Clear read buffer */
223
              memset (charRead, 0, strlen (charRead));
224
              /* Command detected */
225
              return true;
226
          }
227
          else{
228
              return false;
229
          }
230
      }
231
232
     bool pollSerialCmds(USART MODULE ID usartID, const char * command1, const char *
      command2, const char * command3,
233
                             const char * command4)
234
235
          static char charRead[CHAR READ BUFFER SIZE] = {0};
236
          static uint32 t readCnt = 0;
237
238
          // Get command's characters
239
          while((PLIB USART ReceiverDataIsAvailable(usartID))&&(readCnt <</pre>
          CHAR READ BUFFER SIZE)) {
240
              charRead[readCnt] = PLIB USART ReceiverByteReceive(usartID);
241
              readCnt++;
242
          }
          // Command
243
244
          if(readCnt >= CHAR READ BUFFER SIZE)
245
246
              /* Reset read counter */
247
              readCnt = 0;
248
              /* Clear read buffer */
249
              memset(charRead, 0, CHAR READ BUFFER SIZE);
250
          }
          // Check occurence with commands
251
          if((strstr(charRead, command1) != NULL) || (strstr(charRead, command2) != NULL)
252
253
              || (strstr(charRead, command3) != NULL) || (strstr(charRead, command4) != NULL
              )) {
              /* Reset read counter */
254
255
              readCnt = 0;
              /* Clear read buffer */
256
257
             memset(charRead, 0, CHAR READ BUFFER SIZE);
258
              /* Command detected */
259
              return true;
260
          }
          else{
261
262
              return false;
263
264
     /* **************************
265
266
      End of File
267
      */
268
```